



FROM THE INTERIOR, INSTALL LOW PRESSURE POLYURETHANE FOAM BETWEEN WINDOW AND ROUGH OPENING TO MAINTAIN CONTINUITY OF THE AIR BARRIER. IF GAP IS TOO NARROW TO ALLOW FOR USE OF POLYURETHANE, USE A CAULK SEALANT COMPATIBLE WITH FLASHINGS AT THE SILL AND THE JAMBS. IF ZIP SYSTEM® TAPE IS USED AT THE SILL AND THE JAMBS, COMPATIBLE SEALANTS ARE POLYURETHANE, BUTYL, AND SILICONE.

FLANGED WINDOW INSTALLATION DETAIL

DRAWING NOT TO SCALE

06-26-2008

Sales Office: 10925 David Taylor Drive - Suite 300 - Charlotte, NC 28262
Telephone: 800.933.9220 - Facsimile: 704.547.9228 - www.huberwood.com

another innovation from



These construction details are provided to assist in the installation of ZIP System® product(s) and may not apply to every situation. Manufacturer accepts no responsibility or liability for the use of these or other construction details.